



Tecnolux s.r.l.

Via del Lavoro, 12
37060 Trevenzuolo (VR) – ITALY
Tel. +39-045-7350757
Fax +39-045-6680259
Web www.tecnolux-tecnol.it

@mail info@lux-oil.it



MAGIC

WATER HIGH PRESSURE WHEEL WASHER MACHINE

HOW IT WORKS

WASHING PROGRAMS

SHORT PROGRAM – 80 SECONDS : suggested for light density dirty residues

STANDARD PROGRAM – 120 SECONDS: suggested for HEAVY density dirty residues

WASHING PROGRAM – 30 SECONDS : no detergents/steam – only water wash of internal compartment

How it works

- Detergent spouts automatically spray on both wheel sides, covering completely the tyre/wheel surface;
- Software installed adjust detergent quantity to be used;
- High pressure water spouts start working for the selected program ; wheel starts running therefore detergent and water will act for a double act cleaning;
- At the end of the cycle, simply open the frontal door and exit the washed wheel.
- Washing cycle works on internal compartment cleaning; such a function is commonly used by the operator at the end of the working day to erase detergent/dirty residues.

STANDARD MAINTENANCE

- Water draining/collection tanks should be checked every 1000 washing cycles or every three months at least. Such a check is necessary to evaluate and avoid any risk of clogging;
- To drain collection tanks, operator should wait at least 30 minutes from last washing cycle so that impurities and dirt will decant. Open the lower closing panel in the back, pull out the collection tank, connect to the appropriate draining hose with the proper diameter. Open the valve and drain till the tank empties.
- Once collection tanks are empty pull them completely out and clean the residues on the bottom of the tank and dispose them accordingly to your local regulations. At collection tanks cleaning, washing compartment should be cleaned as well . At the end of cleaning procedure, collection tanks must be replaced in their proper location, checking the two tanks connection as properly joined.